



Tuning Guide



V2 - 220719

RS21 TUNING GUIDE							Fixed Forestay - 7892mm
Breeze	Cap Shroud (full turn)*	Tension	Lowars (full turn)*	Tension	Jib Car	Tack Height	Vang
0-6	-2	200	-1	120	1	2.5"	snug to max ease
7-11		275		155	1	2"	snug to max ease
12-15	+4	400	0	155	2	1"	snug +
16-20	+6	475	+1	212.5	3	1"	tight

Base is set at 7-11 knots. Headstay is 120 on gauge with backstay slack | \*Full turns on the adjusters. Tensions using the Spinlock Rig Sense Gauge.



Tuning Guide



V2 - 220719

RS21 TUNING GUIDE							Fixed Forestay - 7892mm
Breeze	Cap Shroud (full turn)*	Tension	Lowars (full turn)*	Tension	Jib Car	Tack Height	Vang
0-6	-2	200	-1	120	1	2.5"	snug to max ease
7-11		275		155	1	2"	snug to max ease
12-15	+4	400	0	155	2	1"	snug +
16-20	+6	475	+1	212.5	3	1"	tight

Base is set at 7-11 knots. Headstay is 120 on gauge with backstay slack | \*Full turns on the adjusters. Tensions using the Spinlock Rig Sense Gauge.